



ASSEMBLY INSTRUCTION

Parts & Installation Procedure


Headrest	Back	Seat	Armrests	Gaslift	Base	Castors
						
(K) × 1	(A) × 1	(B) × 1	(C) × 2	(D) × 1	(F) × 1	(E) × 5



Step 1



Step 2




Step 3



Step 4



Step 5

 (G) × 4 M6*20mm	 (H) × 4 M8*20mm	 (I) × 6
 (J) × 1 4mm	 (M) × 2 M6*16mm	

Installation Instructions

1. Take the castors and push them into the 5 star base, and place the gas strut into 5 star base, it has a tapered fit.
2. Attach armrests into the base of chair(Screw G+ Gasket I)
3. Attach headrest to the backrest(Screw M)
4. Attach the backrest onto the mechanism(Screw H+ Gasket I)
5. Connect the chair mechanism with gaslift on the base

Warning

Please read the instructions carefully before assembly, and assemble the product properly according to the instructions, don't put in use of the product before it is fully assembled.

*To avoid product damage and personal injury, assemble the product properly.

*To avoid product damage and personal injury, please check the product's load capacity and do not support user's whole body on the chair arms. *To avoid personal injury, place the product on the flat ground.

*Do not stand on the product.

*To avoid personal injury, don't use the damaged product, and dispose it properly.

*Indoor use only.

*Only trained people should repair the back angle adjustment component with energy accumulator contained.

*Please keep the instructions in case of further use.